



## 2nd Floor pedestal pan

### design

Sieger Design

### codes

#11009 pan, P-trap  
suits concealed cistern (Sanit)  
#06899 seat, soft close with stainless  
steel hinges

### installation

P-trap installation standard  
#534001 S-trap conversion bend  
105mm set out  
cistern We recommend TECE cisterns

### weight

total weight of toilet suite: 30.6 kg

### Australian Standards & WELS

#11009 AS 1172.2:1999

### instructions

To mount the pan to finished floor one of two methods should be used:

1. Screw/bracket fixing: the pan is fixed directly to the finished floor using mounting brackets and screws supplied. A bed of silicone sealant should be used to correctly seal the pan onto the floor.
2. Bedding on sand & cement mix: the pan should be fixed to the floor using a mixture of 3:1. When bedded, the base of the pan should be approximately 10mm above the finished floor level.

Please note: all height dimensions are taken from base of the toilet pan, so an allowance for bedding thickness is required.

Do not use: lime, white cement or fast drying cement. These may crack the base of the pan.

