



Starck 3 pedestal pan

design

Philippe Starck

codes

#12409	pan, P-trap suits concealed cistern (Sanit)
#06389	seat, soft close with stainless steel hinges
#06381	seat, heavy grade with stainless steel hinges



installation

P-trap installation standard

#534001 S-trap conversion bend
95mm set out

cistern We recommend TECE in wall cisterns

weight

total weight of toilet suite: 29.1 kg

Australian Standards & WELS

#12409 AS 1172.2:1999

WELS 3 Star

instructions

To mount the pan to finished floor one of two methods should be used:

1. Screw/bracket fixing: the pan is fixed directly to the finished floor using mounting brackets and screws supplied. A bed of silicone sealant should be used to correctly seal the pan onto the floor.
2. Bedding on sand & cement mix: the pan should be fixed to the floor using a mixture of 3:1. When bedded, the base of the pan should be approximately 10mm above the finished floor level.

Please note: all height dimensions are taken from base of the toilet pan, so an allowance for bedding thickness is required.

Do not use: lime, white cement or fast drying cement. These may crack the base of the pan.

