



Foster back to wall suite

design

Lord Norman Foster

codes

#17609 pan with adjustable trap
#91200 cistern, dual flush, rear inlet only
#06021 full flush 6 ltr/ half flush 3 ltr
seat, heavy grade with stainless
steel hinges

installation

suits S-trap and P-trap installation
70-190mm set out
Recommended 140mm
#899025 extension piece available
for 190-230mm set out

weight

total weight of toilet suite: 35.8 kg

Australian Standards & WELS

#91200 AS 1172.2:1999
#17609 AS 1172.1:2005, WELS FFF

instructions

Rear water inlet requires 1/2" BSP female flush with finished wall.

To mount the pan to finished floor one of two methods should be used:

1. Screw/bracket fixing: the pan is fixed directly to the finished floor using mounting brackets and screws supplied. A bed of silicone sealant should be used to correctly seal the pan onto the floor.
2. Bedding on sand & cement mix: the pan should be fixed to the floor using a mixture of 3:1. When bedded, the base of the pan should be approximately 10mm above the finished floor level.

Please note: all height dimensions are taken from base of the toilet pan, so an allowance for bedding thickness is required.

Do not use: lime, white cement or fast drying cement. These may crack the base of the pan.

